



Step 1: Assembly Placement

Place the Sorta Stow on the back/outside of the vertical back frame posts. Ensure that the bottom bracket rests on the top of the black polymer cover located at the rear of the seat.

Step 2: Bracket Placement

Position the brackets on the opposite side (inside) of the vertical back frame posts.

Step 3: Secure Assembly

Once the assembly is correctly positioned, tighten the four bolts to secure the brackets to the storage.

Ensure all components are securely fastened for optimal stability and functionality.