

Privacy screen install

1. Loosen screw to pull apart clamp brackets
2. Make sure rubber gaskets are in properly and place screen into position, aligning with edge of the unit
3. Close clamp bracket
4. Tighten screw

