


# SWT2 pneumatic mechanism operating instructions



Top view (as seated)



Front view (as facing chair)

- ① **Seat height adjustment:**  
Lift tab up to adjust seat height
- ① **Back tilt adjustment:**  
Pull rod out to allow tilt, push rod back in to lock tilt
- ② **Back tension adjustment:**  
Turn knob clockwise to increase tension, turn counterclockwise to lessen tension