

SWT4 mechanism operating instructions



Top view (as seated)



Front view (as facing chair)

- ① **Seat height adjustment:**
Lift tab up to adjust seat height