



Top View

front



Front View



- 1 **Seat Height Adjustment:** Lift tab up to adjust seat height
- 2 **Back Tilt Adjustment:** Pull rod out to allow tilt, push rod back to lock tilt
- 3 **Back Tension Adjustment:** Turn knob clockwise to increase tension, turn counterclockwise to lessen tension

Available on

- Revel