
## Sleek mechanism operating instructions



Top view (as seated)



Front view (as facing chair)

- 1) Seat height adjustment:
  - Lift tab up to adjust seat height
- 2 Back tilt adjustment:

Lift tab up to allow tilt, push tab down to lock tilt

**Back tension adjustment:** 

Turn clockwise to increase tension, turn counterclockwise to lessen tension



