



OPERATING INSTRUCTIONS FOR R2 CONTROL

R2 Control Right Side




Left Side




- 1-Seat Height Adjustment
- 2-Back Angle Adjustment
- 3-Back Height Adjustment
- 4-Seat Slider



R2 Control Right Side




Left Side




**Paddle (1):
Seat Height Adjustment**
To raise the seat height: Stand up (or raise your body; so there's no pressure on the seat), lift the paddle to raise the seat height.
To lower the seat height: Sit in the chair and lift the paddle to lower the seat height.

R2 Control Right Side




Left Side




**Paddle (2):
Back Angle Adjustment**
To adjust :When seated, turn the knob towards the front of the seat (clockwise) until the knob is in the first position. Now you can lean back to check the back angle. Turn the knob to the second position to increase the back angle. Turn the knob to the third position for the maximum back angle. Turn the knob towards the back of the seat (counterclockwise) until the knob stops turning to lock the back into the upright position.

R2 Control Right Side



Left Side




**Back Rest (3):
Back Height Adjustment**
To raise the back height: place your hands on the bottom of the back rest and gently push upward.
To lower the back height: Gently push the back rest upward until it reaches its max. The back rest will then fall to the lowest height level.
Note:
Back height adjustment not available on HB chairs.


OPERATING INSTRUCTIONS FOR R2 CONTROL

R2-SS5 Control Only

Right Side



Left Side



R2-SS5 Control Only

Paddle (4):

Seat Slider

To adjust, sit in the chair, lift the paddle and slide the seat forward or back to adjust seat depth. Release the paddle to lock in position.