


ADJUSTING SHELF SUPPORT:

Vertical adjustments can be made by loosening fasteners, adjusting location of shelf support and retightening fasteners.

Horizontal adjustments can be made by sliding shelf support left or right.

Tilt adjustments can be made by turning adjusting screws in or out.

Use a flat screw driver to turn eccentric sleeve to lock the shelf support in place. Sleeve must be rotated on the pin at least a quarter turn.



Slide shelf onto shelf supports until shelf is flush to the wall.